

BURNTECH FIREPLACES

Hearth Rebar Hole Locations

Rebar locations

- Lay-out the position of the fireplace and drill holes where the rebar will be located. Secure eight #3 rebar 4 inches into concrete foundation with ITW Epoxy or Simpson Epoxy.
- Follow manufacturer's instructions for installation of rebar into slab.
- For combustible floors please refer to the installation instructions.

